Europe – EU Declaration of Conformity

The product is conformity with all the essential requirements and other provisions of the European Council Directive: RoHS Directive 2011/65/EU.

Disposal of waste equipment by user in private household in the European Union

This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment.



The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.





User Manual

Please read the user manual carefully before you start using this product

Specifications Dimensions:

Dimensions: 442 x 145 x 21 mm 17.4 x 5.7 x 0.83"

 Weight
 460Gs

 Interface:
 USB-A

 Voltage:
 5V

 Cable*:
 90cm

Key life: 6 million keystrokes
Splash, water, and dust resistant: IP68 Washable

Operating temperature: 10°C ~ 55°C Storage temperature: -20°C ~ 60°C

What's in the box





(with waterproof cap)

A -Waterproof Keyboard

B-User manual

Getting started



Antimicrobial

Keyboard with antimicrobial protection is formulated to suppress the growth of odour and stain-causing microorganisms, and is not intended for use as a replacement to proper hygiene or for prevention of infectious illness.

Cleaning instructions

Your keyboard is hand-washable. Follow the steps below to clean the keyboard without damaging it:

Spray-Wipe-Spray Method

- 1. To avoid accidental keystrokes, entering or deleting important data, LOCK the keyboard by turning on "Cleaning mode" switch
- 2. Clean the surface of the item by wiping, gently brushing, dipping it or by following the "spray-wipe-spray" protocol outlined as follows. Spray the product with disinfecting spray, wipe away dirt and organic solids with a cloth then spray the product completelyagain with disinfecting spray, allowing the disinfectant to remain on the product for at least five seconds.
- 3. Either wipe with dry cloth or shake gently and allow to air dry.
- 4. UNLOCK the keyboard by turning off "Cleaning mode" switch

Sanitisina Dip Method

- To avoid accidental keystrokes, entering or deleting important data, unplug the USB cable from your device before cleaning.
- 2. Cover the waterproof cap and tie the USB cable with the tie on the cap.
- 3. Soak and flush the keyboard with approved cleaning agents.
- Water temperature should be less than 50° C (120° F) and water should not be deeper than 50cm.
- / Recommended cleaning materials: Non-abrasive cleanser, Soap, General purpose cleaner, Disinfectant, Bleach, Surgical spirit.
- DO NOT USE any Petroleum based solvents (e.g., Gasoline, Mineral Spirits, Turpentine), Acetone or cleaning solution containing in excess of 10% bleach. Don't use abrasives.
- 4. Rinse thoroughly to remove any residual cleaning agent.
- 5. Drying the keyboard.
- / Unplug USB waterproof cap, dry of water drops from USB interface with dry tissue.
- Dry off with a clean towel.
- / Do not use a hot-air drier.
- / To extend keyboard life: Recommended to air dry overnight (About 8 hours).

Don't plug a wet cable into your computer.

FCCE © © ** antibacterial technology